

Sound System Setup

1. Place the DJ console centered on your table. There should be a table cloth on the table. As of now, we use two different styles of consoles:



MCX8000



MC6000

2. Setup the speaker poles on each side of the table
3. Place speakers on the poles. Each speaker will need 1 power cord (found in the wire box) and 1 XLR cord (also in the wire box) seen here.
4. Connect the speaker power and XLR cables to the back of each speaker (seen here). The power can be seen in the bottom left corner of this picture. The XLR can either the top or bottom XLR “in” (Plugs in the middle, not the “output”)



5. The other end of the power should go into a power strip you place under the DJ table. The other end of the XLR will go directly into the back of the board (MCX8000 or MC6000)

This image is the back of the MCX8000



You'll plug the XLR into the "Master Out" part (not booth out)



6. Raise each speaker poles so the bottom of the speaker is at the height of your nose.
7. Wires should all be taped with gaff tape in locations where people would step on them as well as against the wall.
8. Leave the microphone case nearby and the backup system under the table. The wire box and game box (if there is one) should be behind you.
9. Place DJ booth or table topper up on the table